



MANUAL OVERRIDE

- JS-1** – One way operation only [extends piston rod]
- JS-2** – Two way [extends or retracts piston rod]
- HO-1** – One way hydraulic [extends piston rod]
- HO-2** Two way hydraulic [extends or retracts piston rod]

NOTE: JS-2, HO-1, and HO-2 overrides are not available on “CEL” Series actuators.